



HOW TO MEASURE FOR YOUR FREEZEPRO® TOTE TANK

Selecting the right size FreezePro® Tote Tank for your equipment is a lot easier than you might think. All you need is a tape measure, and you are ready to go!

CLICK [HERE](#) FOR VIDEO TUTORIAL: HOW TO MEASURE FREEZEPRO® TOTE TANK

WARNING: When installing or measuring for FreezePro® Tote Tank, please follow all safety precautions and use proper and adequate protective safety aids such as: protective glasses and suitable protective clothing. Failure to do so may result in injury.

1. MEASURE FOR THE CIRCUMFERENCE:



CIRCUMFERENCE

2. MEASURE FOR THE HEIGHT:



HEIGHT



3. FIND THE RIGHT FREEZEPRO® TOTE TANK:

FOR EXAMPLE: The CIRCUMFERENCE (length) is 167in and the height is 53in = **FPT 19254.**

HEIGHT

CIRCUMFERENCE	42in (1067mm)	48in (1219mm)	54in (1372mm)	60in (1524mm)	66in (1676mm)
0in-192in (0mm-4877mm)	FPT 19242	FPT 19248	FPT 19254	FPT 19260	FPT 19266

NOTE: Now that you have your measurements, you can use the graph above to help you find the appropriate FreezePro® Tote Tank part number. Circumference (length) measurements are listed in the table rows vertically (Y axis) and height measurements are listed in the column rows horizontally (X axis).

4. FIND THE RIGHT FREEZEPRO® TOTE TANK LID: (OPTIONAL)

WIDTH

LENGTH	40in (1016mm)	42in (1067mm)	46in (1168mm)	48in (1219mm)
42in (1067mm)	N/A	FPTL 4242	N/A	FPTL 4842
48in (1219mm)	FPTL 4840	FPTL 4842	FPTL 4846	FPTL 4848

NOTE: FreezePro® Tote Tank Jackets do not come with an insulated lid. FreezePro® Tote Tank Lids must be ordered/purchased separately. FreezePro® Tote Tank Lids also fit certain sizes so make sure you are buying the right size for your FreezePro® Tote Tank Jacket.



5. GO AND ORDER ONLINE:

1. Go to shop.unitherm.com
2. Enter your part number in to the Search bar in the upper left-hand corner of the page
3. Click "**Search**" to get your FreezePro® Tote Tank Frost Protection Jacket

CLICK [HERE](#) FOR VIDEO TUTORIAL: **UNI THERM SHOP WALKTHROUGH**