



HOW TO INSTALL YOUR UNIVEST® INSULATION JACKET

Installing your UniVest® Insulation Jacket to your selected application is very simply and much easier than you might think.

WARNING: When installing or measuring for UniVest®, please follow all safety precautions and use proper and adequate protective safety aids such as: protective gloves and suitable protective clothing. Keep all metal objects away from heater bands. Never use a metal tape for measuring purposes. Failure to do so may result in injury.

- 1. PLACE THE UNIVEST® INSUALTION JACKET ON THE CYLINDER, WITH THE COLD FACE (GREEN SIDE) FACING UP:**



2. TIGHTEN THE STRAPS & BUCKLES TO SECURE THE UNIVEST[®] INSULATION JACKET ON THE CYLINDER DO NOT OVERTIGHTEN:



3. ONCE YOU HAVE BUCKLED ALL THE STRAPS ON YOUR UNIVEST[®] INSULATION JACKET, YOU ARE READY TO START INSULATING!



Note: After installation, your UniVest[®] Insulation Jacket may have excess coverage on your cylinder. This is normal and is simply added insulation for your application.